## Model S Do It Yourself

Search

Replacing Wiper Blades
For optimum performance, replace the wiper blades at least once a year. Replacement blades must meet the following criteria:

- The blade on the driver's side must be 26 inches (650 mm) long and 20 inches (500 mm) long for the blade on the passenger's side.

  Ensure the connector on the replacement blade is the same as the original blade. Different
- connectors may prevent the replacement blade from connecting to the wiper arm on the vehicle. You can purchase replacement wiper blades on http://www.tesla.com.

Only install replacement blades that are identical to the original blades. Using inappropriate blades can damage the wiper system and windshield.



## To replace the wiper blades:



- Shift into Park and turn off the wipers.
   Touch Controls > Service > Wiper Service Mode > ON to move the wipers to the service position.
   Lift the wiper arm a short distance away from the windshield, just far enough to access the wiper blade.

CAUTION
Wiper blades do not lock into a lifted position. Do not lift a wiper arm beyond its intended position.





- Place a towel between the wiper arm and windshield to avoid scratching or cracking the windshield.
   Hold the wiper arm and press the locking tab while sliding the blade down the arm.



- Align the new wiper blade on the wiper arm and slide it toward the end of the wiper arm until it locks into place.
   Turn Wiper Service Mode off to return the wipers to their normal position.

Do It Yourself General Information Restarting and Powercycling Connecting and Pairing Wheels, Tires, and Brakes Wipers and Washers

Topping Up Windshield Washer Fluid Cleaning Washer Jets

Replacing Wiper Blades

Climate Components Front and Rear Trunk Calibrate Cameras

Low Voltage Battery

Charging © Tesla 2022