

Search

Connecting to Wi-Fi

Wi-Fi is available as a data connection method and is often faster than cellular data networks. Connecting to Wi-Fi is especially useful in areas with limited or no cellular connectivity. To ensure fast, reliable delivery of software and map updates, Tesla recommends leaving Model S connected to a Wi-Fi network whenever possible (for example, when parked overnight).

To connect to a Wi-Fi network:

1. Touch Controls > Wi-Fi icon at the top of the Controls screen. Model S begins to scan and display detected Wi-Fi networks that are within range.

If a known Wi-Fi network does not appear in the list, move Model S closer to the access point or consider using a range extender.



Note When connecting to a 5G network (if available), check which channels are supported in your region.

Table 1. 5G Network Channels
Supported
36-48 52-64 100-140 149-165
X X X X X





- Select the Wi-Fi network you want to use, enter the password (if necessary), then touch Confirm.
 Model S connects to the Wi-Fi network. Whenever the network is within range, Model S connects to it automatically. You can also connect to a hidden network that isn't shown on the list of scanned networks. Just touch Wi-Fi Settings, enter the name of the network in the resulting dialog box, select the security setting, then touch Add Network.

Note

If more than one previously connected network is within range, Model S connects to the one most recently used.







Hotspots and Connectivity
You can also use a mobile hotspot or your phone's Internet connection via Wi-Fi tethering (subject to fees and restrictions of your mobile carrier) to access the internet. To remain connected to Wi-Fi when shifting into Drive or Reverse, choose the connection from the Wi-Fi settings screen, then touch Remain connected in Drive.

Do It Yourself General Information Restarting and Powercycling Connecting and Pairing

Adding and Removing Keys

Connecting to Wi-Fi
Pairing a Bluetooth Phone
Programming HomeLink
Replacing the Key Fob Battery

Unlocking and Starting Using Mobile App Wheels, Tires, and Brakes Wipers and Washers

Climate Components Front and Rear Trunk

Calibrate Cameras Low Voltage Battery

Charging © Tesla 2022