Model 3 Do It Yourself

Search

Adding and Removing Keys

To add a new key card or key fob:

When adding a key fob, ensure it is at room temperature. Pairing a key fob that is very cold can be unsuccessful.

- 1. On the touchscreen, touch Controls > Locks > Keys > Add Key.
- On the Godensereal, fouch Confirms > Locks > Reys > Add Rey.
 Scan your new key card or key fob on the card reader located behind the cup holders on the top of the center console. After the new key card or key fob is recognized, remove it from the card reader.
 Scan a key card or key fob that has already been paired to the vehicle to confirm new key pairing.
 When complete, the key list includes the new key. Touch the associated pencil icon to customize the name of the key.
 Removing a key:

When you no longer want a key to access Model 3 (for example, you lost your phone or key card,

- etc.), follow these steps to remove it.

 1. On the touchscreen, touch Controls > Locks.
- 2. In the key list, find the key that you would like to delete and touch its associated trash icon.
- 3. When prompted, scan an authenticated key card or key fob on the card reader to confirm the deletion. When complete, the key list no longer includes the deleted key.

Model 3 requires at least one authenticated key card or key fob at all times. If only one key card remains on the key list, you cannot delete it.

Do It Yourself General Information Restarting and Powercycling Connecting and Pairing Connecting and Pairing

Adding and Removing Keys
Connecting to Wi-Fi
Pairing a Bluetooth Phone
Programming HomeLink
Wheels, Tires, and Brakes
Wipers and Washers
Doors and Unlocking
Climate Components
Calibrate Cameras and Windows
Front and Rear Trunk
Accessories
Low Voltage Battery
Charging

Charging
© Tesla 2022Feedback